

Автоматические выключатели Emax2

E6.2/MT/f, E6.2/MTP/f

Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(727)345-47-04

Беларусь +375-257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: ahk@nt-rt.ru || сайт: <https://abbswitch.nt-rt.ru>

E6.2/MT/f 6300 MP 4p Earth UP

E6.2/MT/f 6300 MP 4p Earth DOWN

Dimensions

Product Net Depth / Length:	383 mm	383 mm
Product Net Height:	425 mm	425 mm
Product Net Weight:	260 kg	260 kg
Product Net Width:	1055 mm	1055 mm

Container Information

Package Level 1 Depth / Length:	1000 mm	1000 mm
Package Level 1 EAN:		
Package Level 1 Gross Weight:	138 kg	138 kg
Package Level 1 Height:	600 mm	600 mm
Package Level 1 Units:	box 1 piece	box 1 piece
Package Level 1 Width:	515 mm	515 mm

Additional Information

Product Main Type:	SACE Emax 2	SACE Emax 2
Product Name:	Derived Version	Derived Version
Product Type:	Derived version - Earthing truck MT	Derived version - Earthing truck MT
Version:	W	W

Technical

Current Type:	AC	AC
Electrical Durability:	1000 cycle	1000 cycle
Mechanical Durability:	12000 cycle 60 cycles per hour	12000 cycle 60 cycles per hour
Neutral Pole Current ([%I _n]):	100 %	100 %
Number of Poles:	4 / f	4 / f
Rated Current (I _n):	6300 A	6300 A
Rated Impulse Withstand Voltage (U _{imp}):	12 kV	12 kV
Rated Insulation Voltage (U _i):	AC 1000 V	AC 1000 V
Rated Operational Voltage:	690 V AC	690 V AC
Rated Short-time Withstand Current Low Voltage (I _{cw}):	for 1 s 50 kA	for 1 s 50 kA

Rated Uninterrupted Current (I _u):	6300 A	6300 A
Rated Voltage (U _r):	690 V	690 V
Standards:	IEC	IEC
Sub-type:	E6.2	E6.2

	E6.2/MTP/f 6300 MP 4p Earth DOWN	E6.2/MTP/f 6300 MP 4p Earth UP
--	-------------------------------------	-----------------------------------

Dimensions

Product Net Depth / Length:	383 mm	383 mm
Product Net Height:	425 mm	425 mm
Product Net Weight:	116 kg	116 kg
Product Net Width:	1055 mm	1055 mm

Container Information

Package Level 1 Depth / Length:	1000 mm	1000 mm
Package Level 1 EAN:		
Package Level 1 Gross Weight:	143 kg	143 kg
Package Level 1 Height:	600 mm	600 mm
Package Level 1 Units:	box 1 piece	box 1 piece
Package Level 1 Width:	515 mm	515 mm

Additional Information

Product Main Type:	SACE Emax 2	SACE Emax 2
Product Name:	Derived Version	Derived Version
Product Type:	Derived version - Earthing switch with making capacity MTP	Derived version - Earthing switch with making capacity MTP
Version:	W	W



Technical

Current Type:	AC	AC
Electrical Durability:	1000 cycle	1000 cycle
Mechanical Durability:	12000 cycle 60 cycles per hour	12000 cycle 60 cycles per hour
Neutral Pole Current ([%I _u]):	100 %	100 %
Number of Poles:	4 / f	4 / f
Rated Current (I _n):	6300 A	6300 A
Rated Impulse Withstand Voltage (U _{imp}):	12 kV	12 kV
Rated Insulation Voltage (U _i):	AC 1000 V	AC 1000 V
Rated Operational Voltage:	690 V AC	690 V AC
Rated Short-time Withstand Current Low Voltage (I _{cw}):	for 1 s 50 kA	for 1 s 50 kA
Rated Uninterrupted Current (I _u):	6300 A	6300 A
Rated Voltage (U _r):	690 V	690 V
Standards:	IEC	IEC
Sub-type:	E6.2	E6.2



По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(727)345-47-04

Беларусь +375-257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: ahk@nt-rt.ru || сайт: <https://abbswitch.nt-rt.ru>