

Автоматические выключатели

AIR Formula S8H, S8V

Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(727)345-47-04

Беларусь +375-257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: ahk@nt-rt.ru || сайт: <https://abbswitch.nt-rt.ru>

Order codes

SACE Isomax S8 circuit-breaker

F = FIXED



GSIS8019

S8H 2000 $I_n (40^\circ\text{C}) = 2000\text{ A}$ $I_{cu} (415\text{ V}) = 85\text{ kA}$

Microprocessor-based release		PR212 P	code 1SDA0 R1
<i>F = Front terminals</i>			3 poles 4 poles
S8H 2000 F F	In 1600 A	LSI	44861 44877
		LSIG	44863 44879
S8H 2000 F F	In 2000 A	LSI	44862 44878
		LSIG	44864 44880
<i>VR = Vertical flat-bar rear terminals</i>			
S8H 2000 F VR	In 1600 A	LSI	44869 44885
		LSIG	44871 44887
S8H 2000 F VR	In 2000 A	LSI	44870 44886
		LSIG	44872 44888

S8V 2000 $I_n (40^\circ\text{C}) = 2000\text{ A}$ $I_{cu} (415\text{ V}) = 120\text{ kA}$

Microprocessor-based release		PR212 P	code 1SDA0 R1
<i>F = Front terminals</i>			3 poles 4 poles
S8V 2000 F F	In 1600 A	LSI	44918 44934
		LSIG	44920 44936
S8V 2000 F F	In 2000 A	LSI	44919 44935
		LSIG	44921 44937
<i>VR = Vertical flat-bar rear terminals</i>			
S8V 2000 F VR	In 1600 A	LSI	44926 44942
		LSIG	44928 44944
S8V 2000 F VR	In 2000 A	LSI	44927 44943
		LSIG	44929 44945

S8H 2500 $I_n (40^\circ\text{C}) = 2500\text{ A}$ $I_{cu} (415\text{ V}) = 85\text{ kA}$

Microprocessor-based release		PR212 P	code 1SDA0 R1
<i>F = Front terminals</i>			3 poles 4 poles
S8H 2500 F F	In 2500 A	LSI	44891 44899
		LSIG	44892 44900
<i>VR = Vertical flat-bar rear terminals</i>			
S8H 2500 F VR	In 2500 A	LSI	44895 44903
		LSIG	44896 44904

S8V 2500 $I_n (40^\circ\text{C}) = 2500\text{ A}$ $I_{cu} (415\text{ V}) = 120\text{ kA}$

Microprocessor-based release		PR212 P	code 1SDA0 R1
<i>F = Front terminals</i>			3 poles 4 poles
S8V 2500 F F	In 2500 A	LSI	44948 44956
		LSIG	44949 44957
<i>VR = Vertical flat-bar rear terminals</i>			
S8V 2500 F VR	In 2500 A	LSI	44952 44960
		LSIG	44953 44961

S8H 3200 $I_n (40^\circ\text{C}) = 3200\text{ A}$ $I_{cu} (415\text{ V}) = 85\text{ kA}$

Microprocessor-based release		PR212 P	code 1SDA0 R1
<i>VR = Vertical flat-bar rear terminals</i>			3 poles 4 poles
S8H 3200 F VR	In 3200 A	LSI	44908 44912
		LSIG	44909 44913

S8V 3200 $I_n (40^\circ\text{C}) = 3200\text{ A}$ $I_{cu} (415\text{ V}) = 120\text{ kA}$

Microprocessor-based release		PR212 P	code 1SDA0 R1
<i>VR = Vertical flat-bar rear terminals</i>			3 poles 4 poles
S8V 3200 F VR	In 3200 A	LSI	44964 44968
		LSIG	44965 44969

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(727)345-47-04

Беларусь +375-257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: ahk@nt-rt.ru || сайт: <https://abbswitch.nt-rt.ru>